

Finding the Wireless MAC address of a gaming console or smart device.

-This guide provides brief summaries on how to locate a Wireless MAC Address.

- Please note: devices that have both a wired connection port and wireless capability will have separate MAC addresses for each.
- If your device isn't represented here please email the Solution Center at SolutionCenter@thiel.edu or call 724 589 4000 and we'll try to add it.
- If you are having trouble finding your wireless MAC address using the information in this guide, try searching YouTube for videos pertaining to your specific device.

Apple iOS

- 1. Select **Settings** from the home screen.
- 2. Select General
- 3. Select **About**
- 4. Your MAC address will be listed under Wi-Fi Address

Android

Some Android devices differ depending on the manufacturer and which version of Android is running, but in general the MAC address can be found by the following method:

- 1. Select **Settings** from the applications menu
- 2. Near the bottom of the settings menu, select **About Device**
- 3. Select **Status**
- 4. The MAC address will be listed under Wi-Fi MAC Address



Xbox One

- 1. From the main Xbox One homepage, select My Games & Apps
- 2. Select **Settings**
- 3. Select **Network**
- 4. Select Advanced Settings
- 5. Your Wired MAC address will be listed on the right

Xbox 360

- 1. Select My Xbox
- 2. Select **System Settings**
- 3. Select **Network Settings**
- 4. Select **Configure Network**
- 5. Select Advanced Settings from the Additional Settings tab
- 6. Select Alternate Mac Address
- 7. Your wired MAC address will be listed

PlayStation 4

- 1. Select **Settings**
- 2. Select **System**
- 3. Select **System Information**
- 4. Your MAC address will be listed next to MAC address (LAN Cable)

PlayStation 3

- 1. Select **Settings**
- 2. Select System Settings
- 3. Select **System Information**
- 4. Your MAC address will be listed next to MAC address

Nintendo Wii U

- 1. Select System Settings
- 2. Select **Internet**
- 3. Select View MAC Address
- 4. Your MAC address will be listed



Nintendo Switch

- 1. Select **System Settings** from the HOME Menu.
- 2. Scroll down through the menu and select **Internet**
- 3. The Nintendo Switch console's MAC address will be listed under System MAC Address

Nintendo 3DSXL, 3DS, 2DS

- 1. Select **System Settings**
- 2. Select Internet Settings
- 3. Select **Other Information**
- 4. Select Confirm MAC address

Kindle Fire

- 1. From the Home screen, select the **gear icon**
- 2. Select More +
- 3. Select **Device**
- 4. Your MAC address will be listed under Wi-Fi MAC Address

Kindle Paperwhite / First Generation

- 1. From the home screen, select **Menu**
- 2. Select **Settings**
- 3. Select Menu
- 4. Select **Device Info**
- 5. Your MAC address will be listed under Wi-Fi MAC Address

Apple TV

- 1. Select **Settings**
- 2. Select **About**
- 3. Your MAC address will be listed next to Ethernet ID

or

1. You can also find your MAC address on the UPC label of your Apple TV labeled as **Ethernet ID**



Roku

- 1. From the Home screen, press \mathbf{Up} to show the menu bar
- 2. Select **Settings**
- 3. Select **Player Info**
- 4. Your MAC address will be listed

Contact the IT Solution Center at solutioncenter@thiel.edu or 724-589-4000 with any questions or issues